### **DVR Quick Start Guide** Welcome! Let's get started.







104 Install the HDD plate back into DVR and close cover of the DVR

NOTE: The new installed HDD should format

Get to know the Rear Panel



- VIDEO OUT: BNC connector for TV or Monitor
- 4 AUDIO IN: Audio input 5 VGA: VGA output for 19" or larder monitor 6 HDMI: HDMI video output
- LAN: Network(ethernet) port USB PORTS: For mouse & external USB backup
- 9 RS485: RS485 for keyboard or PTZ control 10 DC IN: Power input for 12V DC power supply

onnect monitor DVR VGA or DMI video outp

Section 1 Hardware

A CONNECTION DIAGRAM

1 Connect Camera 2 Connect the other end of to video/power cable to BNG

video/power cable to BNC video input on DVR rear

NOTE

1. The system will pop up a Wizard with the cloud service when you turn on the DVR.
Click on "Next" and "OK" to exist the Wizard.
2. Right click on the screen and you can access to the instant menu bar on the button.
3. When you accessing to the main menu, right click on the mouse you can get back to the previous page.

## HDD Manage

HDD Manage allows you to format the HDD for the new HDD and installed at first time. Access **Main Menu>System**, select on the HDD

Manage icon and access to the HDD manage menu



The DVR will detect the new HDD and you will see the R&W Disk from the list. Select the R&W Disk>click on Format HDD>select"OK"to delete all data.

The interface will be frozen for a few seconds, please wait a few second and waiting the system to restart.

9 Connect mouse to DVR USB input

### Account

Connect the other end of ideo/ power cable (DC onnector only) to power power supply to power splitter an

8 Connect router to DVR Lan port using ethernet cable

power supply to power splitter ar

Connect DVR power supply to DVR

This option allows you to add/modify the users of the DVR. You can modify the password for the new DVR, access to Main menu>System>Account and select the user "Admin" and click on the "Password" option and enter the new password, please note that the default password is blank.

When finished the new password and click the "App and then "OK" to complete the modification

NOTE: The default user "admin" is not allowed to modify. You can add a new user for your personal name or other name if you want.



Select "admin" from the Name as following, leave blank for the old password. Enter the new password and confirm. Click on "APP" and "OK".

### B HARD DISK INSTALLATION If you have purchased a DVR or kit with a HDD, Skip this step.

Remove the screws on the rear panel and side panel, lift the top panel of the DVR up from the

back, and slide it towards the back of the DVR to remove it.



102 Install and fix the HDD with the screws into the bottom panel of the DVR



(13) Connect the SATA data and power cable to the HDD and the mainboard



#### **Section 3 The DVR Setup**

General Configuration



Language - Choose a system language.
Video Standard - Select the correct video standard for your country. USA, Canada is NTSC. **Resolution** - Select a resolution that is suitable for your HDTV or monitor. 1920\*1080 will give you the best

display resolution quality.

System Time - Select the time zone relevant to your region.

HDD Full - Select HDD type by stop or overwrite.

REMIND: After modify the settings, please click App and then ok The DVR will restart after changing the language

# **G** Network Setup



02 Access Main Menu > Network > Network type > Select DHCP (Read more on page 3)



Select "DHCP" on the drop down of the box and click "App" then click "OK". The DVR will be automatically assigned a unique IP address. Make sure the router also enables DHCP.

Please check the network status on the menu, right click on the screen and pup up the menu bar > click on the "info"icon and select the Network Status.

**DHCP**: (Dynamic Host Configuration Protocol) is a system where one device on your network (usually a router) will automatically assign IP addresses to devices connected to the network

**NOTE:** The DVR will match the IP address about 5-10 mins according to your local network

NOTE: If the DVR cannot get the IP address automatically, you can restart the DVR and check the network status again.



NOTE: The interface of the router here only for reference, each router was with different interface.

Access DVR Main Menu > Network > Net Server >double click "Net transmission capacity, port, UPNP" >Enable UPNP>App>

(Port Range: 0-65535, recommend to set the TCP port to 9000, Mobile port to 5000 and Http port to 8002)



The DVR will auto configure the port forwarding of media, HTTP & mobile ports on the router. Make sure the router also enables UPNP function.

NOTE: This is the port that the DVR will use to send information through. The most important things are: You'll need to enable UPnP on your router so your router can selectively open these ports, allowing the DVR to communicate via the Internet.



05 The **DHCP** should have the same information with the DVR.

06 To rotate your mobile phone to horizontal screen

recording icon to start recording

and you will get more menu on the top. Click on the icon to enable the function, click the icon

again to disable the function. For video recording you can select the camera and click on the

### Recording

Access to the menu(Right click on the screen), and click on the third icon to pop up the Record Mode.

Please check current channel status: " means it is in recording status. (The default setting is tick 4CH with auto mode)



Schedule: It records according to the parameters in Main Menu>Video Setting>Record Scheme

Manual: Select the Manual recording and the corresponding channels are recording no matter the channel in any state.

Off: Select off button to turn off all the recording setup.

#### Section 4 P2P Access

Simple way to remote access for Mobile device & Web

**Mobile Access** 


Access to Main Menu>System>P2P QR Code
>Click the check box>OK Make sure the

09

"Connect status" is "Success"

08 Local Video Playback for Mobile Device select the "Video capture file". You'll see the "snapshot" and Record. Using your finger to slide to the video. Select the file and enter to the video.





#### 09 Remote Video Playback from the DVR by Mobile Device

- Click the Remote video on the following (Image 1) Access to the name of your DVR (Image 2)
- Click on the name to search the videos Select the Channel mask (you can select all channels), select the start time and the end time
- Click the search menu on the top of the right (Image 4) and waiting to searching the videos
- The recorded video list was shown on the Image 5 and select the video from the date you want to

Refer the images on page 15

02 Download and install app "HDIVS" from App Store or Google Play. Or you can scan QR code from Main Menu>System>P2P QR Code to download

Select "Register an Account" on the login




address Password: Anyword

MailBox: Your email

04 Enter your account and password to login

**05**) Select " **□** ""**Device management**" to click the add icon on the right top, select the device by



Name: any name

GID: Click to Scan QR code refer to DVR

Main Menu > System > P2P QR code > UUID or you can enter the Serial Number manual into GID bar User name and password: Enter DVR user name

and password (Default user name: admin; No password) By IP: (ONLY for LAN access)
Name: any name
Address: Enter IP address of the
DVR refer to DVR Main Menu >

Network
Port: Enter mobile port of the DVR
refer to DVR Main Menu > Network
>Net server> Network Port> Mobile
port (Default is 5000.)

User name and password: Enter DVR user name and password (Default user name: admin; no password)

Recoding Snapshot ocus out ocus in Ξ. out


want to preview and it will auto connecting to the DVR. Slide the camera to preview more channels



13

11

08



Web Access O1 Setup the Internet Explorer security. (We recommend you to use the latest IE browser)
Run Internet Explorer and go to Internet Options, choose Security Tab and click on Custom level, find "Download unsigned ActiveX controls" and select prompt, then find "**Initialize**" and enable all the ActiveX options, click **OK** and restart Internet Explorer



Run Internet Explorer and go to



Save the ActiveX file and running the ActiveX software, click on Run and click on Next to install

istrator\Downloads\Itp2p (2).exe

Run Cancel

Download the ActiveX from the as shown on

"Download the ActiveX" Download the Act

download it manually.

Always ask before opening this file

The ActiveX will popup automatically or you can

NOTE: Make sure the all the browsers are closed before running the ActiveX.

After installing ActiveX, choose connection by "Device" 
© User 
© Device

UID: Enter the Serial number into "UID" which refer to DVR Main Menu >System>P2P QR code > Serial Number.

Password: Enter the password of the DVR. The default password is blank, if you've setup the new password of the DVR and please enter the new password you've setup.

NOTE: Make sure the ActiveX is installed successful. otherwise you should click "Download the ActiveX" to install manually.

03 Recording by P2P web browser

When you login the http://hdvr.ivs168.com, please click on the "open all" icon on the left, and you can see the recording icon on the right bottom

Select the camera you want to record and click on the icon [ to start recording.



For more information about recording, refer to the manual on the CD

#### Section 5 ISS PC and ISS mobile

Advance mode for professional user, this section is mostly to view more DVR channels in one software



Access Main Menu > Network>Network type>

Select IP Modify the IP Address and Gateway to match your

Router IP address

21

For example: If your router's IP address is 192.168.3.1, then a suitable unique IP address for your DVR will be 192.168.3.xxx(1-255 and make sure the IP was not conflict) and gateway will be 192.168.3.1

NOTE: The above IP address just for a sample purpose



## B ISS Operation

11 Install the "ISS" software from the CD or you

02 Open "ISS" and log in with default user name "**admin**" and no password.

03) Select "Device Manage" from the "Control Panel"



Right click and select the "Add Area" >enter any name ( *E.g.* "Test")> **OK** 



05 Right click on "Test" and select "Add Device".



06 Click "Search Device" to find the devices in the LAN, selects the device in the search list and click "Add" icon. Go back to the control panel and click on the live icon to view the cameras



107 The added DVR will appear on the Device List (Control Panel >Live). Double click on the device to connect the DVR and view the list of camera channels. Move the mouse on the channel list and double click on each camera channel to start live monitoring



The recording icon was one the right bottom of the live interface as shown below, select the camera and click on the recoding icon to



#### 09 Modify the password: Access to Control Panel >User Manager Select the User"admin"Click on the modify icon

and popup a window to enter the new password



For more information about recording, refer to the manual on the  $\ensuremath{\mathsf{CD}}$ 



#### You should deal with a DDNS

We recommend using **HDCCTVDDNS** as your DNS service. This is a free service for DVR owners, which we directly support.

To create an account with DDNS, go to: http://www.hdcctvddns.com and click the Register button. Follow the prompts to create your account.

DDNS is not required for P2P remote access for mobile and web. If you intend to access your DVR using older IP technology you will need to configure this service.

Setup the DDNS on your DVR Access Main Menu > Network>Net Service> Double click the DDNS

Select the  ${\bf DDNS}\ {\bf Type}$  by the DDNS list, select the


"HDCCTVDDNS" and tick the enable icon .

\* Domain Name: Create the host name that you set up in your DDNS service. This is the address you use to access your network.
For example: house 2015.hdcctvddns.com

\* User Name: Enter the user ID (Email address) you have registered from the www.hdcctvddns.co.

\* Password: Enter the password of your registered ID from the www.hdcctvddns.com

\* Click on the "App" and "OK" icon to finish the setup. \* Waiting the network status of DDNS to be connected normally you have to wait a few minutes according to your router response.



## D Login ISS Web Account

Login your ID and password that you've registered from www.hdcctvddns.com and you will see the domain list, click on the domain name and it will link you to the login page of the DVR. Please enter the user and password of your DVR. Click on the "open all" menu to connect all the cameras. You will see the recording icon

was on the right of the bottom. Select the camera you would like to recording and click on the recording icon ( 💷 📂 👩 🕩 🔞

NOTE: please use the latest version of IE browser.



### Mobile Device

20

24

O1 Download and install app "ISSMobile 2" from App store or Google Play.



02 ISS Mobile Interface



1. Menu Camera List 3. Live View 4. Playback Device Logs 6. Device Manager

7. Configuration 8. Live View Channels 9. Multi-channel display

10. Snapshot 11. PTZ control 12. Recording 13. Monitoring 14. Telecom 15. Alarm

16. Resolution 17. Full Screen

18. Video on/off 19. Time Setup

**Device Manager** 

03 Run "ISS Mobile 2" and select Menu >



04 Enter DVR information and select "Save" to add the device

Mode IP/Domin **720P DVR** Alias: any name for

the device Mode: Select "720P DVR"

Address: domain name and insert
 "domain name".hdcctvddns.com
 (E.g. house2015.hdcctvddns.com)

Port: Enter TCP port of the DVR refer to DVR
 Main Menu > Network > Net server > Network Port
 > TCP port (Default is 5000.)

User name and password: Enter DVR user name and password

and password (Default user name: admin; no password) 05 Select "I at the top bar to save. If save

successful, you can see the icon info from Camera No and Start Live View will appear. If not, please check the information and network setting again.

25

Refer the images on page 27




Photo for step07 Photo for step08 Run "ISS Mobile 2" & select Menu>Device Manager

07 If you want to recording by the ISS Mobile please select the camera you want to record and clic on the recording file on the bottom and you will send the relative camera will show with a recording 🗾 , that's means this channel was start recoding

08 Access to Menu , Takes you to the Record List page where you can playback video that you have previously recorded to your mobile device Select the time bar on the bottom to the exact recording period and click on 🗾 to play the

For more information about recording, refer to the manual on the CD

### Section 6 Email and Motion Detection

Email Setup

The DVR will send the alarm information and photos Access Main Menu > Network > Net Service > Double

SMTP server: For example, SMTP server address of Gmail is "smtp.gmail.com".

Port: Email server port number, the default port

number is 25, if you enable the SSL, the port number have to change to 465 Password: enter your password of your email. Sender: Set the email sender address. Theme: The subject of the message, you can set

Recipient: Send an email to the appointed receivers when the alarm is turned on. You can setup the same

email as the sender

Enable SSL: Decide whether to use SSL (Secure Socket Layer) protocol to login, if you enable SSL you have to change the Port number.

#### Motion Detection Configuration Access to Main Menu>Alarm Set>Motion Detect

Channel: Selecting the camera you want to setup the motion detection and select the enable menu Sensitivity: Adjust the sensitivity of motion detection (six options) according to the practical situation



Regional: Click the Setting button, use the mouse or the arrow buttons to highlight the SETUP button for the channel you wish to setup the MOTION DETECTION AREA for, and confirm by pressing select or left click. Right click on the screen to exist the setting.



Period: Click Set button, select one day or all days of detection Period: Click Set button, select one day or all days of detection plan, set the time period (each day is divided into six time sections), then click **OK**, it will start detecting only in the set range. Time Interval: Only one alarm signal is turned on even there are several motion detection signals in this interval.

Delay: Delay a few moments to stop when the alarm state is turned off. The range is 10~300 seconds.

Record channel: Choose the recording channel multiple options supportly.) Trigger the recording

(multiple options supportive). Trigger the recording signal when the alarm is turned on.

Tour: Choose the recording channel (multiple options supportive),

which will tour preview with single screen when the alarm is

turned on.

Prompt: 
means popping the alarm information dialog box in the local host computer's screen.

Send Email: means sending an email to user when the alarm is turned on.