

IP Camera Tester

User Manual

Ver1.2

Regulation




	<p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:</p> <p>(1) This device may not cause harmful interference, and</p> <p>(2) This device must accept any interference received, including interference that may cause undesired operation.</p>
	<p>This symbol on the product or on its packaging indicates that this product shall not be treated as household waste in accordance with Directive 2002/96/EC. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By proper waste handling of this product you ensure that it has no negative consequences for the environment and human health, which could otherwise be caused if this product is thrown into the garbage bin. The recycling of materials will help to conserve natural resources.</p> <p>For more details information about recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.</p>
	<p>Compliance is evidenced by written declaration from our suppliers, assuring that any potential trace contamination levels of restricted substances are below the maximum level set by EU Directive 2002/95/EC, or are exempted due to their application.</p>

Table of Contents

1. Overview	3
2. Screen Layout	4
Status Icons	4
Buttons.....	4
3. Touch Panel Calibration	8
4. AV In/Out (Analog Video In/Out)	10
4.1 AV In—Live View	10
4.1.1 Live View—Speed Dome Camera.....	10
4.1.2 Live View—Fixed Camera.....	12
4.2 AV Out (Color Test Pattern).....	13
5. Setup-AV (Brightness, Sharpness, Contrast)	14
6. Setup-Dome	15
7. Cable Test (CAT5)	17
8. IP Camera (Live View)	19
8.1 Connect (Direct Connecting).....	19
8.2 Device Search.....	21
9. Setup-IP	24
9.1 Setup-IP Connection (Altering Camera Settings).....	26
9.2 Setup-IP Camera (Loading the Network Settings)	27
10. Setup-Snapshot	28
11. PoE Setup	31
12. Setup-Audio (Tester)	33
13. Setup-System	35
Appendix: Technical Specification	39

1. Overview

The IP Camera Tester combines an *analog video tester*, *PTZ camera controller*, and *IP digital video tester* into a single hand-held device, utilizing an ultra-bright, high-resolution 3.5" color LCD screen, which makes all camera adjustments a snap.

IP Camera Tester benefits users by providing various network protocol compatibility. With customized built-in codec, IP Camera Tester is capable of decoding video streaming simultaneously, allowing users to view and to adjust focus on the monitor. The Tester also operates on the NTSC/PAL TV system by standard BNC video input and output. Moreover, it has a phone-jack that allows users to test for audio if available. Furthermore, IP Camera Tester runs off of a rechargeable battery that takes approximately four hours to charge, and provides the Tester with up to three hours of operating time.

Blending functionality and compatibility, IP Camera Tester is a versatile video tester for both analog and IP applications.

Product Features

- Built-in 3.5 inch LTPS LCD monitor with QVGA resolution
- 10 / 100 Ethernet with RJ45 connector
- PTZ control / command parse via Ethernet and RS-485 interface
- Built-in touch panel / keypad.
- High capacity Lithium battery
- UTP cable test
- MJPEG video compression
- NTSC/PAL video in and out / Audio in / speaker out
- Video looping function

2. Screen Layout

Home Screen

The **Home Screen** of the IP Camera Tester is shown as follows:



Status Icons



Battery Status

Indicates the battery level and charging status.

Buttons



Home Screen

Return to the Home Screen.



PSE

When Tester is connected with a PoE-enabled IP Camera, if press the PSE button to enable it lightened, the camera will drain power from Tester's internal battery.



Return

Press this button to go back to the last page.



Enter/Save

Enter a function's submenu or to save setup

**AV In**

Check video displayed on the LCD screen from the analog camera's video output.

**AV Out**

Press the button and enter the video generating mode, which contains various color test patterns for users to check video input of the external display device.

**Connect**

Directly connect to the IP Camera with one touch.

**IP Camera****Device Search**

Ideal for testing multiple IP Cameras. Tap this button, and all the IP Cameras in the network can be found. Then select a specific camera from the IP address/MAC address list.

Users have to access [Setup]-[Setup IP]-[Setup IP connection] for choosing camera type. And relative IP cameras will be filtered out.

**Cable Test**

Detects the CAT5 cable for straight, crossover, shorts, opens and miswire.


**PoE Setup**

Select whether to enable Power over Ethernet (PoE) when booting up. PoE auto-shutdown time can also be specified, which allows to conserve the Tester's battery power.

**Setup**

Various setups for cameras and the IP Camera Tester can be configured here. Each setup is shown in the following section: **Second Screen**.

Second Screen

Press the **Setup**  button in the **Home Screen**, and you will be automatically directed to the **Second Screen** as shown below.



Setup-AV

Adjust analog video's brightness, contrast and sharpness.



Setup-IP

Setup-IP connection

The IP Camera Tester's IP address can be set here. The IP Camera's basic profile including IP address, camera type, user name, password and streaming relevant information is displayed. All the settings can be altered here.



Setup-IP camera

Configure the IP Camera's network settings. Additionally, it is allowed to load the relevant settings from an IP Camera to the Tester.



Setup-DOME

Configure the Speed Dome Camera's protocol, baud rate and ID address.



Setup-Audio

Adjust the volume of IP Camera Tester.



Preview and manage the snapshot files.

Setup-Snapshot




The IP Camera Tester's system settings include LCD brightness, firmware upgrade, factory default reset and auto shutdown setup.


Setup-System

3. Touch Panel Calibration

For initial access or after system reset, users will first enter the Touch Panel Calibration mode (as shown below) before accessing to the **Home Screen**.



- Tap on the flashing cross on the left top of the screen.
- Hit the other flashing cross located diagonally.
- Then touch each flashing box coming out as instructed.




The screen mode will switch to **Home Screen** (see the figure below) after Touch Panel Calibration is completed.




4. AV In/Out (Analog Video In/Out)

Users can test analog video in/out through the BNC **IN/OUT** connectors on the side of the Tester as shown below.



4.1 AV In—Live View

Connect the BNC cable from the connected camera's video output to the Tester's BNC **IN** port. Press the **AV In**  button in the **Home Screen**, and users can view live video from the LCD screen.




4.1.1 Live View—Speed Dome Camera

Users can implement a Speed Dome Camera's PTZ control in the live view mode.





NOTE: Make sure the Speed Dome Camera's RS-485 lines are correctly connected to the Tester's RS-485 terminal block, or PTZ control cannot be manipulated here. For further details, please refer to the Tester's Setup Guide.



Enabling PTZ Control Function

- Please press the **Setup**  button in the **Home Screen** and enter the **Second Screen**.





- Tap the **Setup-DOME**  button and enter its setting page as shown below.






- Select “Enable” from the **Dome type** drop-down list.
- Tap the **Enter/Save**  button to save the setting, and you will be automatically directed to the **Second Screen**.
- Press the **Return**  button to return to the **Home Screen**.

Implementing PTZ Control

- Press the **AV In**  button in the **Home Screen** to enter the live view mode. Meanwhile, there will be four arrow buttons displayed on the screen as shown below.




- Tap the arrows on the screen to *pan* and *tilt* the camera. Press the **Up/Down Shift** Keys (, ) on the Tester's button pad for *zooming in/out*.

Users may adjust video brightness, contrast or sharpness for better live viewing. These settings can be tuned in the **Setup-AV**  setting menu, which is described in [Chapter 4: AV Setup](#).


4.1.2 Live View—Fixed Camera


In the fixed camera's live view mode, there will be the text "AV" displayed on the right bottom of the screen as shown below.



Users may adjust video brightness, contrast or sharpness for better live viewing. These settings can be tuned in the **Setup-AV**  setting menu, which is described in [Chapter 4: Setup-AV \(Brightness, Sharpness, Contrast\)](#).




4.2 AV Out (Color Test Pattern)

Users can verify a monitor's color accuracy with the aid of color test patterns in the **AV Out**  mode. Please connect the BNC cable to the Tester's BNC output (**OUT**) from an external monitor.


Press the **AV Out**  button in the **Home Screen** to enter the **AV Out** menu, which contains eight color test patterns and a Bypass mode.



In the Bypass mode, live video displayed on the Tester can bypass to the external display device.



All the patterns in the **AV Out**  mode can be cycled using the **Left/Right Shift** Keys (, ) of the Tester's keypad or touching the pattern icon on the LCD screen.

5. Setup-AV (Brightness, Sharpness, Contrast)

In the **Setup-AV**  menu, users can adjust analog video's brightness, contrast or sharpness for favorable video display on the Tester's LCD screen under different operating circumstances.



Moving to Setup-AV Menu

- Press the **Setup**  button in the **Home Screen** and enter the **Second Screen**.
- Tap the **Setup-AV**  button to enter the setting page, which is shown below.






In the **Setup-AV** setting page, the live video is displayed on the upper screen.

Adjusting Brightness/Sharpness/Contrast Value


- Move the slider bar by touching the screen or using the Tester's **Left/Right Shift Keys** (←, →).

Switching to Another Item

- Tap the **AV Mode**  button next to the slider bar or press the Tester's **Up/Down Shift Keys** to switch among Brightness, Sharpness and Contrast setting.



Press the **Enter/Save**  button to save all the settings, and you will then automatically directed to the **Second Screen**. Press the **Return**  button to return to the **Home Screen**.


6. Setup-Dome

In the **Setup-DOME**  menu, users can enable/disable PTZ control and configure the Speed Dome Camera's protocol, baud rate and ID address.



Moving to Setup-DOME Menu

- Press the **Setup**  button in the **Home Screen** and enter the **Second Screen**.
- Tap the **Setup-DOME**  button to enter the setting page, which is shown below.



Setting the Dome Type

- Select “Enable” or “Disable” from the **Dome type**’s drop-down list. “Enable” means activating PTZ control on the IP Camera Tester, while “Disable” indicates disabling PTZ control on the Tester.

Setting the Protocol



- Select the protocol for the Speed Dome Camera from the drop-down list.

Setting the Baud Rate

- Select the baud rate for the Speed Dome Camera from the drop-down list.

Setting the ID Address

- Enter the three-digit ID address.

Press the **Enter/Save**  button to save all the settings, and you will then automatically directed to the **Second Screen**. Press the **Return**  button to return to the **Home Screen**.


7. Cable Test (CAT5)

Users can check the RJ45 cable wiring with the supplied UTP Terminal Block


Setup for Testing


- Connect one end of the RJ45 connector to the UTP Terminal Block and the other end to the CAT5 port at the side of the Tester.

Cable Testing


- Press the **CAT5**  button in the **Home Screen**.



- Tap the **Test**  button and wait for wiring detection.



Then the cable's wire map will be displayed on the screen. Users can check the RJ45 cable for its type (Straight/Crossover) and error connection (Shorts, Open, Miswired).

- Press the **Return**  button to return to the **Home Screen**.

8. IP Camera (Live View)

The IP Camera Tester can automatically detect and recognize the IP Camera that is connected to it. Please connect the IP Camera to the Tester's LAN/PoE port; plug in the IP Camera if not using PoE. For further information about PoE use, please refer to [Chapter 10: PoE Setup](#).


Automatic Changing IP Camera Tester's IP Address

After the IP Camera is powered on, the IP Camera Tester's IP address will be automatically changed, which will be displayed on the screen.


Please refer to the following sections for connecting the IP Camera and viewing live video in alternative ways.

8.1 Connect (Direct Connecting)


Enter the Menu for Direct Connecting

- Press the **IP Camera**  button in the **Home Screen** and enter the submenu.




- Check the default camera settings displayed in the field under the **Connect**  button as shown below.



If there is any setting required to be altered, please go to the **Setup-IP connection**  menu to change the related IP Camera settings. See the section [8.1: Setup-IP Connection \(Altering Camera Settings\)](#) for further details.


Proceed to Connect the Camera

- Tap the **Connect**  button in the **IP Camera** submenu, and wait for searching to finish. Then the live video will be displayed on the LCD screen.

Digital PT Control

In the IP Camera's live view mode, there will be the text "ZOOM" displayed on the right bottom of the screen.


- Tap the text "ZOOM", and the video will switch to the digital zoom mode (at max. digital zoom ratio). Meanwhile, the text "PT" will be displayed on the left bottom of the screen as shown below.



- Press the **Left/Right Shift** Keys (⬅️, ➡️), and the image can be horizontally shifted to the left/right with four steps respectively.
- Press the **Up/Down Shift** Keys (⬆️, ⬇️), and the image can be shifted upward/downward with four steps respectively.

To leave the Digital PT Control mode, simply tap the text “ZOOM.”



Exit the Viewing Mode

Press the **ESC** Key  on the Tester’s button pad to exit the live view mode, and return to the **IP Camera** submenu.

IP Camera Profile Display


The IP Camera’s profile details including IP address, camera type, username, password, etc. are shown on the **IP Camera** submenu.


8.2 Device Search

If there are multiple IP Cameras in the network, utilize **Device Search** to find all of the cameras. The **Device Search**  button is in the **IP Camera**  submenu.



Implement Device Search

- Tap the **Device Search**  button, and wait for searching to finish. Then you will enter the Device Search page as shown below.




- Select the IP address of the target camera from the device finding list on the left top of the screen. Then press the **CONNECT** button below the column of Password to start connecting. The live view video will be displayed on the screen.

Digital PT Control

In the IP Camera’s live view mode, there will be the text “ZOOM” displayed on the right bottom of the screen.


- Tap the text “ZOOM”, and the video will switch to the digital zoom mode (at max. digital zoom ratio). Meanwhile, the text “PT” will be displayed on the left bottom of the screen as shown below.






- Press the **Left/Right Shift Keys** (←, →), and the image can be horizontally shifted to the left/right with four steps respectively.
- Press the **Up/Down Shift Keys** (↑, ↓), and the image can be shifted upward/downward with four steps respectively.

To leave the Digital PT Control mode, simply tap the text “ZOOM.”


Exit the Viewing Mode

Press the **ESC** Key  of the Tester's keypad to exit the live view mode, and return to the **IP Camera** submenu.


9. Setup-IP

Users can change the IP Camera's setting, e.g. IP address, camera type, user name, password, streaming format, network settings in the **Setup-IP**  submenus: **Setup-IP connection**  and **Setup-IP camera** .



Move to Setup-IP connection and Setup-IP camera

- Press the **Setup**  button in the **Home Screen** and enter the **Second Screen**.



- Tap the **Setup-IP**  button in the **Second Screen**, and then enter the submenu.




The **Setup-IP connection**  icon and **Setup-IP camera**  icon are in this submenu.



9.1 Setup-IP Connection (Altering Camera Settings)



Press the **Setup-IP connection**  button and enter its setup menu, which is like the following:





Specify Camera Settings

- Please specify the connected IP Camera's IP address, camera type, user name, password, streaming settings, etc. in each column using the stylus touch pen.


Adding a Camera to List


- For adding a camera to the camera list, enter its model name in the **“Camera Profile”** column and click the  button at the right side of this column; while canceling a camera, select the camera to be deleted, and click the  button.


Up to 128 IP Cameras can be assigned for testing.

Press the **Enter/Save**  button to save all the settings. To exit the setup menu, press the **Return**  button.

9.2 Setup-IP Camera (Loading the Network Settings)

For checking or altering the IP Camera's network settings such as Subnet mask, Default gateway, Primary DNS, Web server port, etc., users can go to the **Setup-IP camera**  menu.



Press the **Setup-IP camera**  button and enter its setup menu, which is like the following:



Load Settings from the IP Camera

Please press the **Load from Camera** button on the top of the menu, and the IP Camera's network settings will be shown in the blank field.



NOTE: Make sure the target camera's settings are correctly configured, or the loading here will fail. For altering the camera settings, please go back up one level by pressing the **Return**  button. Then tap the **Setup-IP connection**  button and proceed to change camera settings.

Reload the Settings to the IP Camera


If making any network setting changes, users may press the **Set to Camera** button on the top of the menu for reloading the network settings to the camera.


Press the **Enter/Save**  button to save all the settings.

10. Setup-Snapshot


The advanced snapshot function facilitates saving images in the assigned path when necessary.

Implement Snapshot

- In the IP Camera's live view mode, press the **Snapshot** key  on the Tester's front panel. Then enter the snapshot editing page as shown below.



Snapshot Editing

- Assign a storage location among the three options located on the very top of the snapshot editing page: Tester, USB and SD for the snapshot. Click on the button of the selected item.
- Enter the file name and description respectively for the snapshot.
- Press the **Enter/Save**  button, and the screen will automatically switch to the **Home Screen**.

Files in USB/SD

For files saved in the USB drive or Micro SD card, they will be automatically saved in the file folder named "IMAGE-DATA", which is automatically created. Each snapshot's description can be found in the attached .txt file.

Move to File Managing Page (Setup-Snapshot)

Users can preview each snapshot and copy/delete the image in the snapshot file managing page.





- Press the **Setup**  button in the **Home Screen**.
- Click the **Setup-Snapshot**  button, and enter the snapshot file managing page as shown below.




Image Preview



- In the **Setup-Snapshot** page, select the snapshot storage path (Tester, USB or SD) where the saved files are located. Then all the files will be listed in the **File List** field.
- Select one file within the **File List**, and the image will be displayed in the **Image Preview** field as shown above.

Single File Copy


- Select the file to be copied from one storage path to another from the **File List**.
- Press the **File Copy**  button located in the **File Manager** section below the **Image Preview** field. Then the dialogue of request for selecting a storage path will pop out.
- Click on the selected button and tap the **Enter/Save**  button.

All Files Copy



- Press the **Select All**  button located in the **File Manager** section below the **Image Preview** field, and all the files in the list will be selected.

- Press the **File Copy**  button, and the request for selecting a storage path will pop out.
- Click on the selected button and tap the **Enter/Save**  button. All the snapshot files will be copied to the assigned storage path.

Single File Deletion

- Select the file to be deleted from the **File List**.
- Press the **File Deletion**  button located in the **File Manager** section below the **Image Preview** field. Then the notice of confirmation will pop out.
- Click “OK” to allow deleting the file from the list.

All Files Deletion

- Press the **Select All**  button located in the **File Manager** section below the **Image Preview** field, and all the files in the list will be selected.
- Press the **File Deletion**  button; and the notice of confirmation will pop out.
- Click “OK” to allow deleting all the snapshot files from the list.

11. PoE Setup

The IP Camera Tester can function as the **power sourcing equipment (PSE)** and deliver electricity to the PoE-enabled IP Camera.


IP Camera Tester as the PSE


- Connect the Ethernet cable from the IP Camera to the **LAN/PoE Port** on the side of the Tester.
- Click on the **PSE** button on the top right side of the screen; see the figure below. The PSE indicator will be lit, which means the IP Camera is extracting electricity power from the Tester's battery.




Enable PoE after Tester Bootup

For users who wish to enable PoE in the meantime while the Tester is booting up, please go to the **PoE Setup** page for setup.

- Press the **PoE Setup**  button in the **Home Screen** and enter its setting page as shown below.



- Select “ON” from the drop-down list in “**Enable PoE when booting**”; the Tester will deliver electricity to the IP Camera after system startup.
- Select the PoE auto-shutdown interval: 20 sec., 40 sec. or 60 sec. The setup can aid conserving battery power when there is no IP Camera or other device using the Tester as the PSE. The reminder of PoE shutdown will pop out around 5 seconds in advance of shutting down.
- Click on the selected button and tap the **Enter/Save**  button for saving the settings mentioned above.


12. Setup-Audio (Tester)


The IP Camera Tester's audio volume can be adjusted in the **Setup-Audio** page.


Move to the Setup-Audio Page

- Press the **Setup**  button in the **Home Screen**.





- Tap the **Setup-Audio**  button in the **Second Screen** and enter the audio volume setting page as shown below.





Audio Volume Control

- To adjust the audio volume either by pressing the **Left/Right Shift Keys** (◀, ▶) on the Tester's button pad or touching the screen to move the slider bar.
- Hit the  button next to the slider bar once, and the system will switch to the mute mode.
- Tap the **Enter/Save**  button for saving the audio setting.


13. Setup-System

In the **Setup-System** page, users can adjust the brightness of the IP Camera Tester's LCD screen, implement firmware upgrade and restore all the system settings to factory default.


Move to the Setup-System Page

- Press the **Setup**  button in the **Home Screen**.



- Tap the **Setup-System**  button in the **Second Screen** and enter the Tester's system setup page.







Tester Screen Brightness (Backlight) Adjustment



- Move the slider bar of **Backlight**. Greater value represents higher brightness.
- If click on the **Auto Control** tick box, which is below the **Backlight** slider bar, the screen's brightness level will be fixed. Click on the **Auto Control** button again and cancel the selection; then the slider bar above becomes movable again.

Firmware Upgrade

Before implementing firmware upgrade, please make sure the firmware is located in the path: **upgrade\updt01s** in your USB drive.


- Click the  button, and the file selection dialogue will come out.



- Press the  button, and the firmware in the USB drive shall be found. The firmware details will be displayed in the blank field of the file selection menu.
- Check the **Complete upgrade** tick box, and press the  button for upgrade startup. Then the notice of firmware upgrade confirmation will pop up. Click “OK” and the firmware upgrade will proceed.


Reset to Factory Defaults

Users can restore the Tester system to factory defaults by implementing this function.

- Press the  button. Then the notice of resetting to factory default will pop up. Click “OK” and continue.
- The pop-up message of stating successful reset with request for system reboot will display on the screen. Click “OK” and the Tester will get shutdown.

Touch Panel Calibration after System Reset

Reboot the IP Camera Tester after system reset. You will be first directed to the Touch Panel Calibration mode as shown below.



- Tap on the flashing cross on the left top of the screen.
- Hit the other flashing cross located diagonally.
- Then touch each flashing box coming out as instructed.



The screen mode will switch to **Home Screen** after Touch Panel Calibration is completed.

Auto Shutdown

The system can be automatically shutdown after pre-determined time range when idle.

- Select the specific time interval from the drop-down list for system auto shutdown.
- To disable the **Auto Shutdown** function, please select "OFF" among the options.

Appendix: Technical Specification

IP Camera Tester	
Color LCD Field Display	3.5" (320x240)
AV	
Video Input	BNC x 1
Video Output	BNC x 1
Video Output Signal Format	Video ByPass & Color Patterns x 8
PTZ Camera	
PTZ Control	RS-485
RS-485 Ports	R+, R-, T+, T-
PTZ Camera Setting	Pan, Tilt, Zoom, Manual Focus, Auto Focus
Support Protocols	DSCP, Pelco D, Pelco P, AD422, Panasonic_C, Panasonic_N, JVC, Fastrax 2
IP Camera	
LAN In	10/100 Mbps, 48VDC In, Power Bank In
LAN Out	10/100 Mbps, 802.3af standard
IP Camera Setting	IP address setting, Image setting
Support Brands	DynaColor, ACTi, A-MTK, Axis, Hunt, IQinVision, Luxon, Planet, Pixord, Sanyo, Sony, Vivotek, Zavio
CAT-5	
CAT-5 Port	1
Operation	
Weight include Batteries	450 g
Battery Type	2 × 3.7 V Li-Ion, 2000mAh
Charge Cycles @ 80% capacity	> 300
Charging Time	3.5 Hrs
Operating Time	3 Hrs
Network	
IP Setting	DHCP, Static IP
Size	
Dimension (L×W×H)	170×99×38 mm

General Specifications		
Electronic	Input Voltage	DC12V, 3A
Video	Signal Format	NTSC or PAL
	Video Level	1Vpp, 140IRE
PTZ Control	Data Communication	RS-485
IP Camera	Connection	RJ45
CAT-5 Cable Test	Detects	Straight/Cross Cables, Open, Short, Miswire
USB	Type	USB 2.0
SD Card	Type	SDHC supported
Audio	Input	Line In
	Output	Built-In Speaker Phone Jack Φ 3.5
POE	By Pass / Power Bank	PoE LAN In
	Device	Internal Battery