


Quick Start Guide Vigor2104/2104p

1. Connect the Vigor2104 Series Broadband Router to Your Network



Step1. First, connect the WAN interface to the external ADSL/Cable modem with a RJ-45 cable.

Step2. Connect one port of 4-port switch to your computer with a RJ-45 cable.

Step3. Connect the power cord to the 9V AC port and the power source.

Step4. a. Check the system LEDs. System LED should blink.

b. Check the WAN and LAN LEDs to assure network connections.

Then open web (e.g. IE or Netscape) and enter IP address of the router into the address bar (<http://192.168.1.1>). Later the Setup Wizard pop-up screen will automatically appear.

The router will ask for a user name and password. There is none by default setting, so just leave them the blanks and press "OK". Once the web configurator shows up, you can follow the Quick Start Wizard in Basic Setup Section to configure router quickly.

2. Use the Quick Start Wizard

Step 1

Enter login password.

| | |
|--|--|
| Steps <ol style="list-style-type: none">1. Enter login password2. Select Time Zone3. Connect to the Internet4. Summary | Enter login password <p>There is no default password. For security, please choose a set of number or character (maximum 23 characters) as your password and enter it into the Password box.</p> <p>New Password <input type="text"/></p> |
| <p>Back Next Finish Cancel</p> | |

Then click **Next**.

Step 2

Select the appropriate time zone for your location.

| | |
|--|---|
| Steps <ol style="list-style-type: none">1. Enter login password2. Select Time Zone3. Connect to the Internet4. Summary | Select Time Zone <p>Select the appropriate time zone for your location.</p> <p>Pacific Time (US & Canada) (GMT-8:00) ▾</p> |
| <p>Back Next Finish Cancel</p> | |

Then click **Next**.

Step 3

Select the appropriate connection type to connect to your ISP.

| | |
|--|--|
| Steps <ol style="list-style-type: none">1. Enter login password2. Select Time Zone3. Connect to the Internet4. Summary | Connect to the Internet <p>Select one of the following Internet Access type provided by your ISP. If you are not sure which one you should choose, please contact your ISP to get these information in detail.</p> <p><input type="radio"/> DHCP <input type="radio"/> PPPoE <input type="radio"/> Static IP <input type="radio"/> PPTP</p> |
| <p>Back Next Finish Cancel</p> | |

a. DHCP

If you selected DHCP, this screen will appear.

The screenshot shows a configuration window with a 'Steps' sidebar on the left and a main configuration area on the right. The 'Steps' list includes: 1. Enter login password, 2. Select Time Zone, 3. Connect to the Internet - DHCP (highlighted), and 4. Summary. The main area is titled 'Connect to the Internet' and contains the following text: 'If your ISP require you to enter a specific host name or specific MAC address, please enter it in. The **Clone MAC Address** button is used to copy the MAC address of your Ethernet adapter to the V2104.' Below this text are two input fields: 'Host Name' with the value 'V2104' and '(optional)' to its right, and 'MAC' with the value '00 : 50 : 7F : FF : FF : FF' and '(optional)' to its right. A 'Clone MAC Address' button is located below the MAC field. At the bottom of the window are four buttons: '<< Back', 'Next >>', 'Finish', and 'Cancel'.

Then click **Next** and go to Setp 4.

b. PPPoE

If your ISP uses PPPoE (Point-to-Point Protocol over Ethernet), then select PPPoE. Once PPPoE is selected, you will see this screen. Enter the username and password provided by your ISP.

The screenshot shows a configuration window with a 'Steps' sidebar on the left and a main configuration area on the right. The 'Steps' list includes: 1. Enter login password, 2. Select Time Zone, 3. Connect to the Internet - PPPoE (highlighted), and 4. Summary. The main area is titled 'Connect to the Internet' and contains the text: 'Enter the user name and password provided by your ISP.' Below this are two input fields: 'User Name' with the value 'Anytek' and 'Password' with the value 'Anytek'. Underneath is the 'Connection Type' section with two radio buttons: 'Always On' (selected) and 'Dial On Demand'. Below that is an 'Idle Timeout' field with a small square input box. At the bottom of the window are four buttons: '<< Back', 'Next >>', 'Finish', and 'Cancel'.

Then click **Next** and go to Setp 4.

c. Static IP

If Static IP is selected, then this screen will appear. Enter the IP address information originally provided by your ISP.

The screenshot shows a configuration window with a 'Steps' sidebar on the left and a main configuration area on the right. The 'Steps' list includes: 1. Enter login password, 2. Select Time Zone, 3. Connect to the Internet - Static IP (highlighted), and 4. Summary. The main area is titled 'Connect to the Internet' and contains the text: 'Enter the Static IP configuration provided by your ISP.' Below this are several input fields for IP configuration: 'WAN IP' (172.16.2.20), 'Subnet Mask' (255.255.255.0), 'Gateway' (172.16.2.2), 'Primary DNS' (168.95.1.1), and 'Secondary DNS' (168.95.192.1) with '(optional)' to its right. At the bottom of the window are four buttons: '<< Back', 'Next >>', 'Finish', and 'Cancel'.

Then click **Next** and go to Setp 4.

d. PPTP

If your ISP uses PPTP, then select this option. Once PPTP is selected, this screen will appear. Fill out all the information originally provided by your ISP.

Then click **Next** and go to Setp 4.

Setp 4

When you see this screen, it means your setup is complete. Click Finish. Then restart the router and you can enjoy surfing on the Internet now.

| Steps | Connect to the Internet |
|--|--|
| 1. Enter login password 2. Select Time Zone 3. Connect to the Internet - PPTP 4. Summary | Enter the user name, password, WAN IP configurations and PPTP server IP provided by your ISP. User Name: <input type="text" value="alvarez"/> Password: <input type="text" value="alvarez"/> WAN IP Configurations <input checked="" type="checkbox"/> Obtain an IP address automatically <input type="checkbox"/> Specify an IP address IP Address: <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> Subnet Mask: <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> PPTP Server IP: <input type="text" value=""/> <input type="text" value=""/> <input type="text" value=""/> <input type="button" value="Back"/> <input type="button" value="Next"/> <input type="button" value="Finish"/> <input type="button" value="Cancel"/> |

| Steps | Summary |
|---|---|
| 1. Enter login password 2. Select Time Zone 3. Connect to the Internet 4. Summary | Please find your settings: Internet Access: DHCP Time Zone: Central Time (US & Canada) (GMT-6:00) Click Back to modify changes if necessary. Otherwise, click Finish to save the current settings and restart the Vigo2100. <input type="button" value="Back"/> <input type="button" value="Next"/> <input type="button" value="Finish"/> <input type="button" value="Cancel"/> |

For more information, please refer to the detailed manual in the Provided DrayTek CD. If you have further questions, please contact your local DrayTek dealer, or refer to our support via E-mail, **Fax** or phone. You may also find the latest product information and feature at our website: <http://www.draytek.com.tw>.

